


DMX Lichtplan Bühnenbeleuchtung



● DMX in / out

LED Spot's 1. Pfosten: Kanal 27-30

LED Spot's 2. Pfosten: Kanal 31-34

Vorhangmotor: Kanal 47 auf / 48 zu